


MC2QP Coil Wiring

Coils wired to battery Ignition module switched separately



Coils and Module wired to switched power i. e. Ignition or Kill switch

