
## MC2SP Coil Wiring

Coils wired to battery Ignition module switched separately 12 or 24 Volt



## MC2SP Coil Wiring

Coils wired to battery Ignition module switched separately 12 Volt ONLY

